



# *Spare parts suitable for:* ***ELETTROBAR***


*Spare parts suitable for small appliances and single devices*



## Toasters



| Item | Order  | Description | Model | OEM    |
|------|--------|-------------|-------|--------|
| 1    | 416493 | quartz tube | 406   | 484001 |
| 2    | 416494 | 500W/115V   |       | 233001 |
| 3    | 416495 | 1000W/230V  | 412   | 923003 |




| Item | Order  | Description | Model | OEM    |
|------|--------|-------------|-------|--------|
| 1    | 345547 | switch      | 406   | 213001 |
| 2    | 110339 | knob        |       | 999045 |
| 3    | 345579 | switch      | 412   | 923011 |
| 4    | 110326 | knob        |       | 999081 |




| Item | Order  | Description | Model    | OEM              |
|------|--------|-------------|----------|------------------|
| 1    | 350028 | timer       | 406, 412 | 923012<br>222001 |
| 2    | 110004 | knob        |          | 999044           |
| 3    | 690010 | pliers      |          | 433004           |

## Contact grills




| Item | Order  | Description        | Model                                                       | OEM    |
|------|--------|--------------------|-------------------------------------------------------------|--------|
| 1    | 416496 | 700W/230V (upper)  | 433, 434, 436, 437,<br>438, 439, G33, G34,<br>G37, G38, G39 | 921017 |
| 1    | 416497 | 1000W/230V (lower) |                                                             | 921008 |
| 2    | 690511 | spring             |                                                             | 921005 |




| Item | Order  | Description | Model                                                       | OEM              |
|------|--------|-------------|-------------------------------------------------------------|------------------|
| 1    | 359041 | signal lamp | 433, 434, 436, 437,<br>438, 439, G33, G34,<br>G37, G38, G39 | 216012           |
| 2    | 359042 | signal lamp |                                                             | 216016           |
| 3    | 390139 | thermostat  |                                                             | 921014<br>921046 |
| 4    | 110285 | knob        |                                                             | 921039           |


## Fryers




| Item | Order  | Description | Model | OEM    |
|------|--------|-------------|-------|--------|
| 1    | 416499 | 3300W/230V  | FRI6  | 230069 |
| 2    | 416504 | 3300W/230V  | FRI9  | 230070 |
| 3    | 416505 | 4950W/400V  | FRT9  | 230068 |




| Item | Order  | Description | Model         | OEM    |
|------|--------|-------------|---------------|--------|
| 1    | 416506 | 6600W/400V  | FRI12, FRI15m | 230072 |
| 2    | 416507 | 8250W/400V  | ME15, ME30    | 230073 |
| 3    | 416508 | 10950W/400V | ME20, ME40    | 230074 |




| Item | Order  | Description       | Model         | OEM              |
|------|--------|-------------------|---------------|------------------|
| 1    | 375507 | safety thermostat | universal     | 236034<br>236045 |
| 2    | 380238 | protection        | FRI6/9/12/15m | 229032           |
| 3    | 380423 | protection        | ME15/20/30/40 | 229016           |
| 4    | 359041 | signal lamp       |               | 216012           |




| Item | Order  | Description | Model       | OEM              |
|------|--------|-------------|-------------|------------------|
| 1    | 345547 | switch      | ME15, ME20, | 213001           |
| 2    | 110339 | knob        | ME30, ME40  | 447059           |
| 3    | 375618 | thermostat  | universal   | 236033<br>236044 |
| 4    | 110354 | knob        |             | 921002<br>447147 |



| Item | Order    | Description  | Model           | OEM    |
|------|----------|--------------|-----------------|--------|
| 1    | 550061   | sensor clamp | FRI6/9 (230 V)  | 033286 |
| 2    | 550062   | sensor clamp | FRI6-15 (400 V) | 033287 |
| 3    | n. l. a. | sensor clamp | ME_             | 033278 |



| Item | Order  | Description       | Model       | OEM    |
|------|--------|-------------------|-------------|--------|
| 1    | 101131 | Minisit           |             | 611001 |
| 2    | 101136 | cover with Piezzo | MG15, MG20, | 611002 |
| 3    | 110068 | knob              | MG30, MG40  | 447060 |
| 4    | 101265 | interrupter       |             | 468068 |



| Item | Order  | Description    | Model       | OEM    |
|------|--------|----------------|-------------|--------|
| 1    | 100192 | pilot burner   |             | 611003 |
| 2    | 102094 | thermocouple   | MG15, MG20, | 611005 |
| 3    | 100701 | electrode      | MG30, MG40  | 611006 |
| 4    | 100026 | ignition cable |             | 611007 |




| Item | Order  | Description       | Model    | OEM    |
|------|--------|-------------------|----------|--------|
| 1    | 375200 | safety thermostat | MG_      | 236015 |
| 2    | 540699 | drain tap         | FRI      | 720008 |
| 3    | 540646 | drain tap         | ME_, MG_ | 720010 |



| Item | Order  | Description | Model         | OEM    |
|------|--------|-------------|---------------|--------|
| 1    | 970294 | basket      | FRI6          | 706088 |
| 2    | 970295 | basket      | FRI9          | 706089 |
| 3    | 970296 | basket      | FRI12, FRI15m | 706090 |



| Item | Order  | Description | Model       | OEM    |
|------|--------|-------------|-------------|--------|
| 1    | 970297 | basket 1/2  | ME15, ME30, | 706097 |
| 2    | 970298 | basket 1/1  | MG15, MG30  | 706092 |



| Item | Order  | Description | Model       | OEM    |
|------|--------|-------------|-------------|--------|
| 1    | 970299 | basket 1/2  | ME20, ME40, | 706096 |
| 2    | 970300 | basket 1/1  | MG20, MG40  | 706093 |